

Please follow the illustrated steps below to hang and install your **SMART PANEL** radiator:

1. Take the radiator out of its packaging and choose where to hang it. Please note the minimum distances required around the heater ^{*2}.
2. The flap of the box has the guide printed on it to place the radiator on the wall. You must make the holes of the template to Drill and plug the holes.
3. Place the box against the wall and mark where the supports should be placed.
4. **If you have an anti-roll**, once the holes in the box have been marked as a guide, mark the hole in the 3rd bracket, taking measurements as indicated in the diagram ^{*3}.
5. Drill and attach the plugs.
6. Screw the brackets to hold the radiator into place, using the screws and washers provided.
7. Place the wall spacer in the centrer slot on the back of the computer. Leave it on the bottom.
8. Place the radiator on the wall brackets.

